



PHONE USER GUIDE: Grandstream GXP2130/GXP2160

| Function | Action | Notes |
|-----------------------------------|---|---|
| Answer Incoming Call | Pickup handset or press the speaker button on phone | Answers calls to your phone |
| Make Outbound Call | Dial phone number or Extension and press the speaker or pickup handset | Dialing phone number before picking up handset or pressing speaker will execute the call immediately. You may also dial traditionally by picking up the handset, then dialing number, then pressing the send button on the phone. |
| Do Not Disturb | Press Mute button | Will prevent your phone from receiving inbound calls. Calls will deliver to voicemail. |
| Voicemail | Press Envelope image button on Phone, or dial * <extension></extension> | Allows user to access user's voicemail box. User will be prompted for password. |
| Redial | Press the "Redial" softkey | Redials last called number. |
| Call Park | Press Assigned Green Button BLF | Park a call. |
| Pick Up Parked Call | Press Assigned Red Button BLF | Pick up a parked call. |
| Attended Transfer | Press Line 2 > Dial Extension + Dial, then + Line 1 after accepted | This will allow you to call the Extension privately before the transfer of a call. |
| Blind Transfer | + Extension + Transfer | This will blindly transfer calls to an Extension |
| Transfer directly to Voicemail | + Extension + * + Transfer | Used to transfer a call to a user's voicemail box without first ringing the user's phone. |
| Intercom | *90 + <extension></extension> | Automatically opens a channel to another phone. |
| Conference | Press + Dial Number + Press dial > ConfCall | Adds a second party to existing call. |